


# NOSE ASSEMBLY DATA SHEET



## CAUTION!

Do not operate if pintail deflector is removed. Pintail may eject forcibly. SEVERE PERSONAL INJURY MAY RESULT.

\*GB752 USE 752142 STROKE LIMITER.

\*\*GB722 USE 722142 STROKE LIMITER.

\*\*\*MOST FASTENERS REQUIRE MORE THAN ONE PULL.




6/17 REV 10/25

## GAGE BILT MADE in USA

44766 Centre Court Clinton Twp. MI 48038 USA  
Ph: +1 (586) 226-1500 Fax: +1 (586) 226-1505  
solutions1@gagebilt.com / www.gagebilt.com

| Type:                    | Fasteners:                                                                                            | Recommended Tool:                     |
|--------------------------|-------------------------------------------------------------------------------------------------------|---------------------------------------|
| Single Action<br>5/32" Ø | EN6122 & UAB130-EU<br>EN6127 & UAB6127-EU<br>EN6128 & UAB100-EU<br>EN6129 & UABP-EU<br>MAXIBOLT® PLUS | GB751                                 |
|                          |                                                                                                       | Alternate Tools:<br>**GB722<br>*GB752 |

| Ref. No. | Qty. | Description             | UAB05-751C-54RA |
|----------|------|-------------------------|-----------------|
| 1        | 1    | Nose Tip                | 15598           |
| 2        | 1    | Anvil Holder            | 10115           |
| 3        | 1    | Jam Nut                 | 70411           |
| 4        | 1    | Collet                  | 20327           |
| 5        | 1    | Super Grip Jaw Assembly | 30529-S4        |
| 6        | 1    | Frame                   | 75310           |
| 7        | 2    | Shoe Bearing            | 75311           |
| 8        | 1    | Drawbolt Collet         | 70486           |
| 9        | 1    | Barbed Retainer         | 70575           |
| 10       | 1    | Deflector               | 61107           |
| 11       | 1    | Lever                   | 75313           |
| 12       | 1    | Button Head Cap Screw   | 402471          |
| 13       | 2    | Set Screw               | 75315           |
| 14       | 1    | Guard                   | 75316           |
| 15       | 2    | Pivot Pin               | 75317           |
| 16       | 8    | Link                    | 75318           |
| 17       | 4    | Link Pin                | 75319           |
| 18       | 1    | Bellcrank               | 75320           |
| 19       | 1    | Guide Pin               | 75321           |
| 20       | 1    | Drawbolt                | 75322           |
| 21       | 1    | Adapter Assembly        | 70459           |
| 22       | 1    | Extension-Collet        | 70463           |



## ATTACHMENT:

Disconnect air supply from tool. Hold back of drawbolt-collet (8) down with thumb. Thread anvil holder (2) into frame (6) until it bottoms out on collet (4). Loosen approximately 1/4 turn and tighten jam nut (3) securely to frame (6). Engage one or two threads of extension-collet (22) onto piston assy located on tool, then insert adapter assy (21) into end of head cylinder assy located on tool and turn clockwise until snug. Rotate nose assembly to desired position and tighten adapter assy (21) securely. Reconnect air supply to tool.

## DISASSEMBLY:

Loosen jam nut (3) and remove holder (2). Unscrew collet (4) which contains super grip jaw assy (5) from drawbolt-collet (8).

Remove button head cap screw (12) and guard (14). Remove two set screws (13) and push out two pivot pins (15) to permit removal of linkage. Shoe bearings (7) and drawbolt-collet (8) will disengage from lever (11).

Remove four link pins (17) to disassemble lever (11), links (16), bellcrank (18) and drawbolt (20).

Remove guide pin (19) from frame (6). Adapter Assy (21) is secured to frame with Loctite® and need not be removed unless damaged.

## REASSEMBLY:

Reverse the procedure. Linkage, consisting of lever (11), links (16), bellcrank (18) and drawbolt (20) should be assembled as a subassembly before inserting lever (11) into shoe bearings (7) and drawbolt-collet (8). MAKE SURE NOTCHES ON DRAWBOLT-COLLET (8) ARE POINTING TOWARDS LEVER (11). This complete subassembly may then be inserted into frame (6) and retained by guide pin (19) and pivot pins (15).